

# Aurora Quik-Roll™ Security Door

## Installation Guide

### 1 Remove the guide rails

1 Carefully cut the shrink wrap from guide rails and remove from box.



2 Unscrew the wood from the box and remove.

### 2 Remove all other pieces which are taped inside box.



Verify that the following items are enclosed:

- a. 1 complete rolling door
- b. 2 guide rail assemblies
- c. 1 packet with clips, 1/4" wrench, etc.

### 3 Remove the rolling door and lay on a flat surface.



### 4 Remove plastic & foam end pieces from door.



### 5 Follow the "Internal Packaging Removal" Instructions, enclosed.

## Affixing Clips and Guide Rails

### 6 Attach the guide rail assembly to shelving.

Place the left guide rail assembly on the face of the left upright end panel.



### 7 Attach clip to shelving and guide rail assembly.



While holding the guide rail in place, clip the guide rail assembly to the shelving end panel.

## 8 Lightly tighten screws



Turn the 1/4" wrench to lightly tighten screws, allowing some wiggle room.

## 9 Attach remaining clips

Attach the remaining clips to the guide rail assemblies, evenly spacing them with:

- one at the top,
- two in between,
- and one at the bottom.



## 10 Attach other guide rail

# Inserting Doors into Guide Rails

## 11 Lift door over guide rails



## 12 Slide ears into rails

Slide the ears of the door end caps into the guide rails.



**TAKE CAUTION ON THIS PART!!!** The end cap ears are cast aluminum and break easily with too much pressure.

## 13 Tighten with 1/4" wrench



Once the door is in place, use the 1/4" wrench to fully tighten the screws.

## 14 Installation Complete!



Congratulations- You have successfully installed a Rollok door.

Test the door to ensure that everything works properly.